

Quick Start Guide

SMS - 920 / 930

Sign Making System



Safety Instructions

When set up correctly and installed according to instructions, the printer should not present any hazards.

The following possible dangers exist:

- Injury from the cutter assembly.
- Hair, clothes and jewellery pulled into the printer, during operation with the cover open
- Only use the printer in protected environments.
- Do not spill any liquids into the printer.
- Only have your printer repaired by specially trained service personnel.
- In any event of danger or damage to the printer, turn the printer off and remove from the power supply..
- Turn the printer off and remove from the power supply before cleaning.

Technical Information



General Specifications

Specification	SMS - 920 / 930
Print Technology	Thermal transfer
Resolution	300 dpi (12 dots/mm)
Print speed	5-15cm/sec (2-6 Inch/s)
Print length	127cm (50 inch)
Print width	21,5cm
Memory	8 MB Flash memory 32 MB SDRAM
CPU type	32-bit high performance processor
Sensors	Transmissive/ gap sensor (position adjustable from 4“ ~ 8“) Reflective black mark sensor (position full web adjustable) Transmissive ribbon end sensor Ribbon encoder sensor Head open sensor
LCD Display	Graphic type, 128 x 64 pixel, with back light
Operator interface	6 operation buttons
Communicatie interface	USB - Centronics parallel (LPT) – 100Mbit Network port
Fonts	Internal character sets. 5 alfa numeric fonts from 1,25mm~6,0mm All fonts can be scaled 24x24 4 rotation positions 0°-90°-180°-270° Soft fonts can be downloaded.
2D Barcodes	Maxicode, PDF-417, Data Matrix
Wieght	23.2kg
Power	Input: 90-264VAC, 47-63Hz
Classifications	CE, UL, CUL, FCC class A, CCC
Operating environment	Operation: 5°C ~ 40°C, 20% ~ 85% non-condensing

Machine overview


Quick Installation Guide

Printer Overview




Loading Ribbon

Loading Ribbon









Control Panel



LED	Status	Indication	Keys	Function
① POWER	Off	Printer power off	≡ MENU	1. Enter the menu system 2. Once in the menu system, return to previous menu. If at menu root, exits the menu system.
	On	Printer power on		② PAUSE Pauses or resumes printing
② ON-LINE	On	Printer is ready	↑ FEED	Advances one label
	Blinking	Printer is paused Printer is downloading data		UP ⌈ Scroll up the menu options
③ ERROR	Off	Printer is ready	DOWN ⌋	Scroll down the menu options
	On	Carriage open OR Cutter error	SELECT	Select the currently highlighted option
	Blinking	No paper, Paper jam OR No ribbon		

Loading Media

Loading Media

		<p>(1) Push the printhead release lever to open the printhead mechanism. (2) Lift the empty media roll up and move the rollguards wider. Place the new media roll.</p>
		
<p>(3) Pull the leading edge of the label forward through the media guide bar past media sensor, and place the leading edge onto the platen roller.</p>	<p>(4) Adjust the label guide to fit label width.</p>	<p>(5) Close printhead mechanism, making sure the latches are engaged properly.</p>
<p>* Loading path for media</p> 		
<p>(6) Using the front display panel, set media sensor type and calibrate the selected sensor (See "Media Sensor Calibration" on facing page). Note: Re-calibrate the gap/black-mark sensors when changing media.</p>		