

USER MANUAL

SMS - 400



SMS 400
SIGN MAKING SYSTEM



Table of Contents

Introduction	4
Proprietary Statement	4
Product Improvements	4
FCC Compliance Statement.....	4
Liability Disclaimer.....	4
Getting Started.....	6
Unpacking Printer.....	6
Package Contents	7
Printer Overview.....	8
Front View	8
Rear View.....	9
Interior View I	10
Interior View II	11
Attaching Power	12
Loading Media.....	13
Preparing Media.....	13
Placing Media Roll	13
Loading Ribbon	19
Preparing Ribbon	19
Placing Ribbon Rolls	20
3. Printer Operations	25
Printing Media Calibration & Configuration.....	25
Steps to Start Media Calibration & Configuration ..	25
Sample of Printer Configuration Label	26
Printer Controls and Indicators	28
Troubleshooting by LED Indicators Diagnosis	31
Miscellaneous.....	34
Recovery	35
4. Communications.....	36

Interfaces and Requirements	36
USB Interface Requirements	36
Serial (RS-232) Interface Requirements	36
Serial Cabling Requirements	37
Ethernet 10/100 Internal Printer Server Option.....	37
Ethernet Module Status Indicators	38
Communicating with the Printer	38
Installing the Printer Driver (USB).....	39
Configure network adapter (DHCP/Static IP).....	40
Installing the Printer Driver (Ethernet LAN).....	41
Caring for Your Printer.....	42
Print Head Maintenance Guide	42
Cleaning Interval.....	42
Cleaning Material.....	42
Cleaning Direction	43
Product Specification	44
General Specification.....	44
Fonts, Barcodes, and Graphics Specification	45
Printer Programming Language PPLB.....	45
Interface Specification.....	47
USB Interface	47
Serial Interface	47
Ethernet Interface	48
Appendix.....	51
Rotary Cutter Installation	51
Rotary Cutter with Paper Jam.....	57

Introduction

Proprietary Statement

This manual contains proprietary information of Rebo B.V. It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the expressed written permission of Rebo B.V.

Product Improvements

Continuous improvement of products is a policy of Rebo B.V. All specifications and signs are subject to change without notice.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into a different outlet on a different circuit.
- Consult the dealer or an experience Radio/TV technician for help.

This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance. The user is cautioned that any changes or modifications not expressly approved by Rebo B.V. could void the user's authority to operate the equipment.

Liability Disclaimer

Rebo B.V. takes steps to assure that the company's published engineering specifications and manuals are correct; however, errors do occur. Rebo B.V. reserves the right to correct any such errors and disclaims any resulting liability. In no event shall Rebo B.V. or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, damages for loss of business profits,

business interruption, loss of business information, or other pecuniary loss) arising out of the use of or the results of use of or inability to use such product, even if Rebo B.V. has been advised of the possibility of such damages.

CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Getting Started

Congratulations with your SMS-400 purchase.

The SMS-400 printer is ideally designed to easily bring more efficiency for your business. This manual will help you get to know your new printer and provide sufficient information needed.

Unpacking Printer

After receiving your printer, please check for possible shipping damage:


Inspect the outside of both the box and the printer for possible damage.

1. Open the top cover of the printer to see if all parts are in order.

Note: *If shipping damage has been discovered, contact your shipping company immediately to file a claim.*

2. Check whether you have received the following accessories together with the printer. If there is any item missing, please contact your local dealer.


Package Contents




- Quick Installation Guide
- Power Cord
- Media Hanger & Media Shields
- Printer
- Power Supply
- USB cable
- Ribbon Core Adaptors
- 1" ID Core for Ribbon

Printer Overview


Front View




Rear View



Interior View I



Interior View II




Attaching Power

1. Make sure the printer's power switch is in the off position (down).
2. Insert the AC power cord into the power supply.
3. Insert the power supply's power connector into the printer's power jack.
4. Plug the other end of the power cord into an appropriate grounded AC electrical outlet.

Warning:

Do not operate the printer and power supply in an area where
they




Loading Media

Preparing Media


The inside wound or outside wound media rolls can be loaded into the printer in the same way. In case media roll may become dirty or dusty during shipment, handling, or storage, firstly remove the outside length of media, which helps to avoid dragging adhesive or dirty media between the print head and platen roller. When loading media, it must be placed onto the media hangers.

Placing Media Roll


1. Open Top Cover of the printer.




2. Put the Media Hanger through media supply roll, and then centrally align with the two Media Shields to closely lean against the media supply roll.




3. Locate the media supply roll into the Media Compartment of printer.




4. Push the Release Latch to open the printer module.




5. Pull a short length of media till it reaches the Platen Roll of printer.




6. Press the lock of Media Guide at the right to adjust media guides' positions. Make sure media stays under the Media Shaft and centrally under both of the Media Guides.




7. Close the printer module and then press firmly at the both sides to properly latch until you hear a click.



8. Press the FEED button to feed labels out of the printer.



9. To tear media, pull the media edge against the Tear Bar as in the direction below:



Loading Ribbon

The following steps only apply to thermal transfer printing mode only.


Direct thermal does not need ribbon to be installed.

Note:

- Media and ribbon types should be matched to provide with optimal print results.
- Always use ribbon that is wider than the media to protect the print head from wear.
- For direct thermal printing, do not load ribbon in the printer.


Preparing Ribbon

Find the two Ribbon Core Adaptors in printer package and fix them into new ribbon rolls from the left to the right.




Placing Ribbon Rolls


1. Open Top Cover of the printer.




2. Push the Release Latch to open the printer module.



3. Lift up the printer module to check the Ribbon Supply Holder.




4. Install one ribbon roll and rotate it until the notches align and lock into the left side of Ribbon Supply hub, and then into the right.



Note:

The Ribbon Supply Holder accepts the coated side of ribbon to be wound ink-side IN or wound ink-side OUT.


5. Install the other ribbon roll and rotate it until the notches align and lock into the left side of Ribbon Pick-up hub, and then the right.




Note:

The Ribbon Pick-up Holder accepts the coated side of ribbon to be wound ink-side OUT only.

6. Close the printer module and then press firmly at the both sides to properly latch it until you hear a click.



7. Rotate Thumb Wheel of Ribbon Pick-up Holder to remove slack and ribbon wrinkle, and to align the ribbon on the spindles.



3. Printer Operations

Printing Media Calibration & Configuration

Before connecting the printer to your computer, to make sure that the printer works properly, conduct media calibration and print a self-test/ configuration label.

Steps to Start Media Calibration & Configuration

1. Make sure the media is properly loaded and the top cover of the printer is closed.
2. Turn off the printer power.
3. Press and hold the FEED button while turning on the power, until printer motor is activated.
4. Media Calibration will be performed while the printer automatically feeds the label stock for a certain length; then the printer motor suspends for one second and then prints out configuration/ self-test labels. Release the FEED button as soon as printer starts to print.

Note:

Printer will enter Dump mode after printing configuration. In Dump mode, all characters will be printed in 2 columns: the right shows characters received from your system, and the left are the corresponding hexadecimal values of the characters. It allows users or engineers to verify and debug the program.

To return to normal operation mode from Dump mode, press the FEED button again. Another way is to turn off printer power, and then restart printer.

Sample of Printer Configuration Label

Label Printer with Firmware
 SMS-400 B01.09 112714 01
 STANDARD RAM: 8M BYTES **PERO FUNCTION ENABLED**
 AVAILABLE RAM: 5144K BYTES
 FLASH TYPE:ON BOARD 8M BYTES
 AVAILABLE FLASH: 6143K BYTES
 8 bit data: Code Page 437
 THERMAL TRANSFER
 REFLECTIVE SENSOR(NORMAL)
 REF:1B30 SEE2:3EFE
 NO. OF DL SOFT FONTS : 0
 Int. fonts: NO DOWNLOADED FONTS
 CUT COUNT: 14816
 PRINT LENGTH METER: 1881 M
 RS232 : 9600, 8, N, 1P
 CHECKSUM : 00000000
 SPEED: 2IPS DARKNESS: 10
 MEDIA TYPE: CONTINUOUS
 PRINT WIDTH: 1248
 LABEL LENGTH: 1821
 BACKFEED: DISABLE
 CUTTER: DISABLE
 CUTTER OFFSET: 0
 $R(X,Y) = R(23,0)$
 H. POSITION ADJUST : 0000
 CALIBRATION TYPE: MODE 1
 M(6300,0,0,0)
 Ethernet version: 1.01
 IP address: 192,168,1,100
 Subnet mask: 255,255,255,0
 Gateway: 192,168,1,100
 MAC address: 00-11-E5-03-70-41
 SNMP: DISABLE
 s(2,25)
 U2368,84,2,0,25664,53184,180
 5,5,5,5,5,5,5,5,1,
 ON

ON	OFF	0	0
OFF	0	0	0
SW2	1	2	3
	4	5	

 This is internal font 1. 0123456789 ABCabcXYZ
 This is internal font 2. 0123456789 ABCabcXYZ
 This is internal font 3. 0123456789 ABCabcXYZ
 This is internal font 4. 0123456789 ABCXYZ
THIS IS INTERNAL FONT 5.

Resetting Printer to Factory Defaults

Follow the steps below to reset printer to default settings:

1. Turn on the printer and wait till both "Ready" indicator and "Power" indicator stay solid green.
2. Press the "FEED" button for 4 seconds, and the "Ready" indicator and "Power" indicator will go off in order.

(at this step, if the "FEED" button is pressed for 8 seconds, printer will reset first >> feed blank labels as media calibration >> and then print configuration/ self-test labels.)


3. Once "Power" indicator becomes lit again, release the FEED button.
4. "Ready" indicator will then become lit, too. At this moment, the printer has resumed its factory default settings.

Printer will delete those print tasks received but not yet printed.

Note:

The printer factory default settings are stored in printer's flash; these settings remain stored, without being erased even the printer power is disconnected.

Printer Controls and Indicators



The following table explains printer controls and indicators' functions to help understanding LED indications and printer status:

Control / Indicator	Function
Power Switch	<ul style="list-style-type: none"> On: turns on normal operation (at “I” position) Off: turns off power (at “O” position) <p>Note: Turn power off before connecting or disconnecting cables</p>
Power LED	<ul style="list-style-type: none"> It will start blinking while “Media Out”, “Media Gap Not Found” or “Ribbon Out” has been detected. Once printer cutter mode has been enabled, when Cutter is jammed with paper or Cutter is not installed, POWER indicator will blink. When RS-232 communication error is detected, POWER indicator will blink.
Ready LED	<ul style="list-style-type: none"> When printer is started, the READY indicator will blink. In Ethernet model, the READY indicator will blink for several seconds to wait till Ethernet Card is ready. When printer receives data from host PC, READY indicator will start blinking. READY indicator will blink when printing is paused. It will start blinking while “Media Out”, “Media Gap Not Found” or “Ribbon Out” has been detected. It will blink as soon as the printer module is

	<p>opened.</p> <p>Note:</p> <p>When the print head is over-heated, printer's thermal protection function will be activated and make READY LED blink to indicate printer is in PAUSE status to wait till print head has been cooled down. The printing tasks sent previously will be resumed automatically later.</p>
Feed Button	<ul style="list-style-type: none">• Press to advance the label media to the first printing position.• Press during printing to make printer "pause".• Press and hold while switching on the power to conduct media calibration and print out a configuration profile.• To resume printing after "Media Out "or "Ribbon Out " errors have been resolved.

Troubleshooting by LED Indicators Diagnosis

Normally, when the printer is not working properly, the "Power" LED blinks continuously, and printing and communication between the host and printer stops. Refer to LED indications listed below to understand possible solutions to resolve the problems printer run into.

LED Indicators: Power and Ready LEDs blink at the same tempo

Power LED	Ready LED
ON	ON
OFF	OFF

Possible Problems	Solutions	Remarks
Media sensor cannot index label gaps	Check the label path Check the label sensor	If a continuous label roll is in use, set "continuous media" printing in driver settings or commands.
Media out	Install a new label roll	
Paper jam	Recover the jam	

LED Indicators: Power and Ready LEDs blink alternately

Power LED	Ready LED
ON	OFF
OFF	ON

Possible Problems	Solutions	Remarks
Ribbon out	Install a new ribbon roll	Set "Direct Thermal" printing by driver or commands if no ribbon is required.

LED Indicators: Only the Power LED blinks

Power LED	Ready LED
ON	ON
OFF	ON

Possible Problems	Solutions	Remarks
Serial IO error	Check serial baud rate at both of your system and the printer.	For serial interface only
Cutter has failed, or there is paper jam inside the cutter.	Check the cutter or recover paper jam.	Only applicable when cutter mode to cutter mode.
Other possible hardware errors.	Contact the reseller for further service.	

LED Indicators: Only the Ready LED blinks

Power LED	Ready LED
ON	ON
ON	OFF

Possible Problems	Solutions
Print head needs to cool down	Printing will stop until the print head cools to normal printing temperature. Once it completes, the printer will automatically resume the printing tasks sent previously.
Printer head module unlatched	Close the printer module and then press firmly at both the left and the right of printer module to properly latch.
Printer is in PAUSE status	Press FEED button to resume printing.
Printer is receiving data	As soon as all the data has been received, Ready LED will stay solid green and automatically resume normal operation.


Miscellaneous

If the host shows "Printer Time out":

1. Check if the communication cable (serial) is connected securely to your serial port on the PC and to the connector on the printer at the other end.
2. Check if the printer power is turned on.

If the data has been sent, but there is no output from the printer. Check the active printer driver, and see if NiceLabel driver for your Windows system and the label printer has been selected.

Vertical streaks in the printout usually indicate a dirty or faulty print head. (Refer to the following examples.)



Clean the print head. If the problem persists, replace the print head.

Poor printout quality:

- The ribbon may not be qualified.
- The media may not be qualified.
- Adjust the Darkness (heat temperature).
- Slow down the print speed.
- Refer to the next chapter and clean the related spare parts.

Recovery

After correcting problems, simply press the panel button or restart the printer to continue your print jobs. Make sure the LEDs are not blinking and remember to resend your files.

4. Communications

Interfaces and Requirements

The SMS-400 printer comes with a nine-pin Electronics Industries Association (EIA) RS-232 serial data interface, a USB interface, and Ethernet. A variety of interface options are suitable for versatile applications:

Note:

1. You must insert the power supply's barrel connector into the power jack on the back of the printer before connecting communication cables.
2. This printer complies with FCC Rules and Regulations, Part 15, for Class A Equipment, for use with fully shielded six-foot data cables. Use of longer cables or unshielded cables may increase radiated emissions above Class A limits.

USB Interface Requirements

The Universal Serial Bus (USB) interface is compatible with your existing PC hardware. The USB's "plug and play" design makes installation easy. Multiple printers can share a single USB port/hub.

Serial (RS-232) Interface Requirements

The required cable must have a nine-pin "D" type male connector on one end, which is plugged into the mating serial port located on the back of the printer. The other end of the signal interface cable connects to a serial port on the host computer.

Note:

For technical and pin-out information, please refer to the Technical Reference, Interface Specifications in this manual.

Serial Cabling Requirements

Data cables must be of fully shielded construction and fitted with metal or metalized connector shells. Shielded cables and connectors are required to prevent radiation and reception of electrical noise.

To minimize electrical noise pickup in the cable:

1. Keep data cables as short as possible.
(6 ft or 1.83m recommended)
2. Do not tightly bundle the data cables with power cords.
3. Do not tie the data cables to power wire conduits.

Ethernet 10/100 Internal Printer Server Option

This connector is for Ethernet application; it is convenient to use several printers by Ethernet connector at the same time.


Note:

When using Ethernet model printer, please wait till the Ready Indicator to stop blinking, before starting printer operations.

Ethernet Module Status Indicators

LED Status	Description	
Both Off	No Ethernet link detected.	
Blinking	The printer waits for printer ready. It will take about 20 seconds to be ready.	
Green	Speed LED	On: 100 Mbps link Off: 10 Mbps link
Amber	Link/Activity LED	On: link up Off: link down Flash: activity

Ethernet LED Indicators:



Communicating with the Printer

The bundled printer driver can be applied to all applications under Windows 7 / 8 / 10, supporting 32-bit and 64-bit operation systems. With this driver you can operate any popular Windows software application including NiceLabel label editing software or MS Word, etc., to print to this printer.

Installing the Printer Driver (USB)

1. Plug the power cable into the power socket on the wall, and then connect the other end of the cable to printer's power socket. Turn on the printer.
2. Note: do **not** connect the USB cable from PC to printer yet.
3. Download the SMS Printer Drivers from Rebo Systems website. Start the SMS.EXE executable and click Unzip. Click OK to confirm. The printer installation tool will start.
4. Click Next and click Install Printer Driver, accept the license agreement.
5. Select option USB port, then connect the USB cable.
6. The printer model will be detected, enable option Launch installation of SMS Printer Utility if desired (recommended, you can use it to see printer firmware settings and network adapter settings).
Click Install, then click Exit.
7. The printer has been added to Windows.

Configure network adapter (DHCP/Static IP)

1. Connect the SMS - 400 with a USB cable to your computer and use the SMS Printer Utility to set network settings.
2. Start SMS Printer Utility
In Windows Devices & Printers window, right mouse click printer SMS - 400 and select Printing Preferences, go to Advanced Settings tab, click the Printer Utility button near the bottom. Or use the shortcut on your desktop.
3. On the Printer Setting tab, select model SMS – 400 and Interface: USB. Select Network to see the available settings.

Decide if you want to use DHCP or Static IP and choose below:

If you want to use DHCP:

4. Enable option DHCP. Click Send. After 5 seconds, turn your printer off. DHCP (Automatic IP) is now enabled.
5. The MAC address of the printer is available on a label on the bottom of the printer (including barcode, you can scan it). Create an IP address reservation on the DHCP server, then turn printer on. Make sure the Ethernet cable is connected before turning on the printer.

If you want to set a Static IP:

4. Enable option IP Address and Subnet Mask, set desired IP address and Subnet Mask. Click Send. After 5 seconds, turn your printer off. Static IP and Subnet are now set. Turn the printer on and wait 20 seconds.
5. Enable option Gateway and set desired gateway. Click Send. After 5 seconds, turn your printer off. Gateway is now set. Turn the printer on and wait 20 seconds.
Make sure the Ethernet cable is connected before turning on the printer.

Installing the Printer Driver (Ethernet LAN)

1. Setup the network settings as described in chapter **Setup Ethernet module IP (DHCP or Static IP) on page 39**.
2. Plug the power cable into the power socket on the wall, and then connect the other end of the cable to printer's power socket. Connect the Ethernet cable and turn on the printer.
3. Download the SMS Printer Drivers from Rebo Systems website. Start the SMS.EXE executable and click Unzip. Click OK to confirm. The printer installation tool will start.
4. Click Next and click Install Printer Driver, accept the license agreement.
5. Select option Network port, then select model SMS-400.
6. Select Create a new network port and click Next.
7. Fill in the desired port name and the IP Address which has been assigned to the printer. Click Next.
8. Enable option Launch installation of SMS Printer Utility if desired (to be able to set printer firmware and network settings).
Click Install, then click Exit.
9. The printer has been added to Windows.

Caring for Your Printer

Print Head Maintenance Guide

To keep the Print Head remain in the best conditions and efficiency and to extend duration for use, regular cleaning action is needed:

Note: Always switch off printer power before cleaning. In case of long-time printing, surface of print head may be very hot. Please wait till print head cools down properly before maintenance, to prevent burns. During maintenance, do not directly touch print head surface, to avoid its damage and any possible injury to you. Use cleaning material instead.

Cleaning Interval

It's strongly recommended to regularly clean print heads at least when changing every one label roll (in direct thermal printing mode) or every one ribbon roll (in thermal transfer printing mode). In addition, if printers are operated under critical applications and environments, or if it's found that print quality is degraded, please clean print heads more frequently.

Cleaning Material

Surface of print head's heating element is very fragile. To prevent from any possible damage, please use soft cloth/ cotton buds with "Ethanol" or "IPA" to clean print head surface.


It's strongly recommended to wear hand gloves during cleaning progress.

Do not touch print head surface by bare hands or with any hard equipment.

Water or spit should be kept away in case of corrosion on heating elements.

Cleaning Direction

When cleaning the print head, always wipe in One-Way Direction - from Left to Right only, or, from Right to Left only, to clean "Heating Line" of print head gently without excessive stress. Do not wipe back and forth, to avoid dust or dirt on cleaning cotton would be attached onto print head again.



Special Caution:

Warranty of print heads will be void if print head serial number is removed, altered, defected, or made illegible, under every circumstance.

Product Specification

General Specification

Specifications	SMS-400
Printing Method	Direct Thermal / Thermal Transfer
Printing Resolution	300 dpi (12 dots/mm)
Printing Speed	(25.4~101.6 mm/s)
Printing Length	Max 50"(1270mm) Min 0.2"(5mm)
Printing Width	Max 4.1"(104mm)
Memory	8MB DRAM (5MB user available) 8MB Flash ROM (6MB user available)
CPU Type	32 bit RISC microprocessor
Sensors	Media Reflective sensor x 1 (movable) & Media Transmissive sensor x 1 (Center fixed) / Head open switch / Ribbon end sensor
Operation Interface	LED indicator (Power/Ready)x 2, Button(Feed) x 1
Communication Interface	Ethernet, RS-232(Baud rate: 2400~115200 bps), USB
Emulation	PPLB
Software - Label editing	We recommend NiceLabel
Software – Utility	Printer Utility, Font Utility
Media Type	Roll-feed, die-cut, continuous, fan-fold, tags, ticket in thermal paper or plain paper and fabric label
Media	Max Width:4.33"(110mm) Min Width:1"(25.4mm) Thickness:0.0025"~0.01"(0.0635~0.254mm) Max roll capacity(OD):5"(127mm) Core size:1"(25.4mm) / Max roll capacity(OD):4.5"(114.3mm) Core size:0.5"(12.7mm) (optional) / Max roll capacity(OD):4.72"(120mm) Core size:1.5"(38.1mm) (optional) Min Length: 0.79"(20mm) for rotary cutter option
Ribbon	Ribbon roll – max OD: 2.6"(67mm) Ribbon Length: max 300m Core size – ID: 1"(25.4mm)

	Ribbon Width: 1"~4", Wax, Wax/Resin, Resin (Ribbon wound ink-side out or ink-side in)
Dimensions	L 273mm x W 225mm x H 186mm
Weight	2.1kg
Power Source	Universal Switching Power Supply Input: 100~240V, 1.5A, 50-60Hz, Output: 24VDC, 2.91A
Operation Environment	Operation Temperature: 40°F~100°F (4°C~38°C), 10% ~ 90% non-condensing, Storage Temperature: -4°F~122°F (-20°C~50°C)
Optional Items	Cutter unit
Agency Listing	CE, FCC, cTUVus, CCC, RoHS

Fonts, Barcodes, and Graphics Specification

The specifications of fonts, bar codes and graphics depends on the printer emulation. The emulation PPLB is a printer programming language, through which the host can communicate with your printer.

Printer Programming Language PPLB

Programming Language	PPLB
Internal fonts	5 fonts with different point size

Symbol sets (Code pages)	8 bits code page : 437, 850, 852, 860, 863, 865, 857, 861, 862, 855, 866, 737, 851, 869, 1252, 1250, 1251, 1253, 1254, 1255 7 bits code page: USA, BRITISH, GERMAN, FRENCH, DANISH, ITALIAN, SPANISH, SWEDISH and SWISS (300dpi printer models support Code page 437, 850, 852, 860, 863, 865, 1254 only)
Soft fonts	Downloadable soft fonts by Font Utility
Font size	1x1 to 24x24 times
Character rotation	0, 90, 180, 270 degree, 4 direction rotation
Graphics	PCX , Binary Raster, BMP and GDI
1D Barcodes	Code 39、UPC-A、UPC-E、Matrix 2 of 5、UPC-Interleaved 2 of 5、 Code 39 with check sum digit 、Code 93、EAN-13、EAN-8 (Standard, 2 /5digit add-on) 、 Codabar、Postnet、Code128 subset A/B/C、 Code 128 UCC (shipping container code) 、 Code 128 auto、UCC/EAN code 128 (GS1-128) 、Interleave 2 of 5、Interleaved 2 of 5 with check sum、Interleaved 2 of 5 with human readable check digit、German Postcode、Matrix 2 of 5、UPC Interleaved 2 of 5、EAN-13 2/5 digit add-on、UPCA 2/5 digit add-on、UPCE 2/5 digit add-on、 GS1 Data bar (RSS)
2D Barcodes	MaxiCode、PDF417、Data Matrix (ECC 200 only) 、QR code、Composite Codes


Interface Specification

This section presents the interface specifications of IO ports for the printer. These include pin assignments, protocols and detailed information about how to properly interface your printer with your host or terminal.

USB Interface

Connector Terminal Pin Assignment

Pin	Signal	Description
1	VBUS	5V
2	D -	Differential data signaling pair -
3	D +	Differential data signaling pair +
4	GND	Ground



USB series "B" Receptacle Interface

Serial Interface

The RS232 connector on the printer side is a female, DB-9.



Pin	Signal	Description
1	No function	Shorted to Pin - 6

2	Received Data, RxD	Input. Serial “Received Data”
3	Transmitted Data, TxD	Output. Serial “Transmitted Data”.
4	No function	No connection
5	GND	Signal Ground
6	No function	Shorted to Pin - 1
7	Request to Send, RTS	Output. Used as the control signal for “H/W Flow Control”
8	Clear to Send, CTS	Input. Used as the control signal for “H/W Flow Control”
9	+5V	Output. Pin 9 is reserved for KDU (keyboard device unit)

Note :


Pin 9 are reserved for KDU (keyboard device unit), therefore do not connect these pins if you are using a general host like a PC.

Ethernet Interface

The following port complies with Ethernet communication.

Pin	Signal
1	Transmit+
2	Transmit-
3	Receive+
4	Reserved
5	Reserved
6	Receive-
7	Reserved
8	Reserved




1 2 3 4 5 6 7




Connection with Host

Host 25S (PC or compatible)	Printer 9P	Host 9S (PC or compatible)	Printer 9P
DTR 20 1 DSR	DTR 4 1 DSR
DSR 6 6 DTR	DSR 6 6 DTR
TX 2 2 RX	TX 3 2 RX
RX 3 3 TX	RX 2 3 TX
CTS 5 7 RTS	CTS 8 7 RTS
RTS 4 8 CTR	RTS 7 8 CTS
GND 7 5 GND	GND 5 5 GND

Alternatively you can just connect the 3 wires in the following way.

Host 25S (PC or compatible)	Printer 9P	Host 9S (PC or compatible)	Printer 9P
TX 2 2 RX	TX 3 2 RX
RX 3 3 TX	RX 2 3 TX
GND 7 5 GND	GND 5 5 GND
pin 4		pin 4	
pin 5		pin 6	
pin 6		pin 7	

pin 20



pin 8

The simplest way to connect to other hosts (not PC compatible) or terminals is:

Printer	Terminal/Host
Pin 2- RxData	TxDATA
Pin 3- TxDATA	RxDATA
Pin 5- Ground	Ground

In general, as long as the data quantity is not too large and you use Xon/Xoff as flow control, it will be problem free.

Baud rate: 2400, 4800, 9600(default), 19200, 38400, 57600, 115200 bauds.(programmable by command)

Data format: always 8 data bits, 1 start bit and 1 stop bit.

Parity: always non parity

Handshaking: XON/XOFF as well as CTS/RTS (hardware flow control).

If you run an application with the bundled printer driver under Windows and use the serial port, you should check the above parameters and set the flow control to "Xon/Xoff " or "hardware".


Appendix

Rotary Cutter Installation


Warning: Blades inside cutters are quite sharp. To ensure your safety, never attempt to insert fingers or objects into rotary cutter or guillotine cutter. During all cutter operations including installation, adjustment, or recovery from paper jam, please power off printer first and unplug printer's power cord.

Refer to the following steps to install the cutter kit onto printers:


1. Power off the printer.
2. Open Top Cover. Remove Front Cover.



3. Loose the two screws (item 2) under Bottom (item 1).
4. Pull out to unlatch the front side of Middle Cover (item 3) and then remove it upward from Bottom .
5. Loose the four screws (item 4) at both sides of Printer Module to take Printer Module off from Bottom.
6. Find Cutter Baby Board in cutter package (item 5), and then install onto **JP16** socket on printer main board.



7. Remove Mylar Film from Printer Chassis. Thread Cutter Cable through the hole where Mylar Film locates, and then connect to JP9 connector (CUTTER) on printer main board. Cutter Cable should go through the hooks under Printer Chassis to manage cables better.
Make sure Cutter Cable go upon the font side of Middle Cover.




8. Assemble back Printer Chassis and Middle Cover.
9. Pull the font side of Middle Cover. Then assemble back with Bottom downward.
10. Fix the two screws to Bottom.

11. Install Cutter Module by fixing Cutter Bracket (item 6) on Printer Chassis with screws.
12. Close Printer Module and Top Cover.

Now cutter installation has been completed through the steps above.

To load media, please refer to the section – Loading Media.



Rotary Cutter with Paper Jam

If there is paper jam inside rotary cutter, refer to Rotary Cutter Installation section to remove the rotary cutter. Check the Cam as marked in Figure 1; find a slotted screwdriver to turn counter-clockwise as Figure 2. During turning the Cam of cutter, release the blade from paper and them remove the paper from the cutter.

Figure 1.



Figure 2.

