

Download the software: [Bepop CM-200 Software CD 00-12.zip](#)

This is the latest available version and works on Windows 7, 8, 8.1 and 10 during our tests.

Install the software while logged in with a local Administrator account.

We recommend to disable Microsoft driver signature enforcement before starting the installation (see Troubleshooting chapter on how to do this).

Software installation

1. Extract the **.zip** file.
2. Open folder \English\App\ and start **setup.exe**. Follow the wizard to install the software.

Driver installation

1. Make sure the **.zip** file has been extracted as described for the software installation.
2. **Connect** the CM-200 with a **USB** cable to the computer and **turn on** the CM-200.
3. In Windows, open Devices & Printers. In the top of this window, click the button **Add a printer**.
4. Choose the bottom option: **The printer I want to use, is not in the list**.
5. Choose the bottom option: **Add a local printer or network printer with manual settings**.
6. Choose **Use existing port** and choose port **USB001**. If you can also see port USB002 or USB003 in the list: the vinyl cutter is normally the **highest number**.
7. Click **Browse** and again **Browse**.
32 bit Windows, open folder: \NSetup\CMDriver\English\VISTA
64 bit Windows, open folder: \NSetup\CMDriver\English\64
and select file **maxcmvec.INF**. Click **Open** and click **OK**.
8. Select printer model **MAX CM-200** and click **3x** the **Next** button, then click **Finish**.

Troubleshooting

Does adding the printer driver result in a continuous loop at the end of the wizard? This can happen on Windows 8, 8.1 and 10.

The cause of this is Microsoft **driver signature enforcement**, which doesn't allow unsigned 3rd party drivers to be installed. **To disable this, see instructions below**.

After restarting, you will be able to install the driver normally; however, Windows will display a warning message. When the warning appears, click **Install this driver software anyway**.

For Windows 8, follow these steps:

- Windows key + I
- Change PC settings
- General
- Advanced Startups > Restart Now

- Troubleshoot
- Advanced options
- Startup Settings
- Restart
- Type number 7 on your keyboard to select: Disable driver signature enforcement

For Windows 8.1, follow these steps:

- Windows key + I
- Change PC settings
- Update & Recovery
- Recovery
- Advanced startup > Restart Now
- Troubleshoot
- Advanced options
- Startup Settings
- Restart
- Type number 7 on your keyboard to select: Disable driver signature enforcement

For Windows 10, follow these steps:

- Open menu start > Settings > Update & Security > Recovery > Restart now
- Troubleshoot
- Advanced Options
- Startup Settings
- Restart
- Type number 7 on your keyboard to select: Disable driver signature enforcement